



Our Kits Include...

**SHEDS**



**SCREEN ROOMS**



**AWNINGS**



**SPECIALTY ITEMS**



And so much more...

## Do It Yourself Patio Covers & Carports

### Fixed Insulated Patio Covers

**We will gladly supply our customers with a quotation under the following guidelines...**

Our pre-engineered kits are put together to conform to 2006 International Building Code standards. We will not help our customers take short cuts. For your safety and insurance purposes we will need the following information before considering your request for quotation...

**You will need to obtain, from your local building department,** a "pounds per square foot" load requirement as well as a "miles per hour" wind load requirement. We use these numbers to determine which thickness of panel you need (we have 3), what size beam you will need (we have 7 different sizes!), where the beam should go (for safety), how many posts are necessary and the spacing between posts!

\*\*As you can see, these numbers are VERY important for both safety and to make sure you are not paying for more than you need!

**Measuring** (see diagram below for terminology)

- We will need a back wall height measurement - either how high on your house wall will you be attaching your patio cover or the ground to eave measurement if attaching to the front fascia board
- We will need your desired projection and width. If you are covering the entire deck, we suggest a 1' overhang on both sides and the front
- We will need to know if you are attaching the unit to an existing deck or patio surface OR are you cementing the posts into the ground.
- We will need to know if you have a chimney work-around with all the measurements. Extra inside and outside corners will be provided.

**Not Included in our Kits:**

- Downspouts are not included. Let us know if you require them. They are \$35.00 for a basic 8' assembly. They are easily picked up locally and this would give you the freedom to create the shape you need.
- Flashing is not included. When doing a fascia board mount, you will need to flash 3" under the shingles and about 12" out onto your patio cover. On a wall mount, "L" flashing would go under the siding and again about 12" out onto your patio cover.
- Hardware to attach the back-wall fascia gutter to house wall or fascia board is not included.

We are available by telephone or by email to answer questions on any of our Do-It-Yourself Home Improvement kits. We will guide you in selecting the proper kit, in the proper size that will work with your home. We are experts in kit assembly and can answer your questions BEFORE you make a decision to buy. **Call us for FREE advice with No obligation at (800) 922-4760.**


We offer a **5% discount** on any product for remittance of a certified / cashier's check. We save money on credit card fees and pass them on to you.

Best Wishes,

*Bob, Shawn, Glenn*

The Team

# Home Attached System



ScreenHouses Unlimited  
52 Riverview Beach Road  
Pefferlaw, ON L0E 1N0

[www.ScreenHousesUnlimited.com](http://www.ScreenHousesUnlimited.com)

Toll Free: (800) 922-4760  
Fax: (705) 735-0360  
Email: [requests@screen-house.com](mailto:requests@screen-house.com)